

Luminous-Stones- AW-1501 ~ AW-1506

G-COLLECTION

- DO NOT put the goods onto soiled floor.
- DO NOT crease the goods.
- DO NOT get paste on the face of the product.
- Follow the **UP** instruction onto the backside.
- Hung straight and side match.
- USE soft bristle brush and urethane seam roller. Do not use a metal knife or stiff sweep.
- Hang wallcoverings with pre-trimmed edges on butt-Joints.
This product can not be double seam cut on the wall.
Trim the material from the back side on a table. To make a template for cutting is recommended.
- Cut with a very sharp, single edge razor blade from the face side at top and bottom of each strip.
- USE Factory Edges on butt-Joints
- Remove Glass Beads at back side of the goods during installation, if any.
- DO NOT have longer relaxing time. (Usual relaxing time: 5-15 Minutes)
- Wipe off excess paste immediately with soft damp cloth. Do not scrub and rub.

1 General Guidelines

- Ensure that you have received the correct products, all material have same lot number before installation.
- Please inspect the goods for defects carefully prior to installation.
- Product claims will not be considered on cut or installed material after three panels have been installed.
- Seams may be obvious upon installation, this is not considered a defect.

2 Wall Preparation

- Ensure surfaces are clean, smooth, dry, firm and uniformly colored.
If not, necessary remedy works are required.
- Walls should be primed with a good quality primer.

3 Installation

- Use a Heavy Duty, Clear, Pre-Mixed, Water-Based Adhesive. Do not dilute the adhesive.
- Apply the paste to the back of the wallcoverings evenly, which will become flexible and easy to hang.
- Do not use too much adhesive to avoid seam tearing stains on the wallcovering.
- Allow to rest 5 to 15 minutes.
- Apply wallcoverings to the wall using a soft bristle nylon brush carefully. Do not use a metal knife or stiff sweep.
- This design is meant to be straight hung and side matched, due to its pattern. Vertical Repeat:640mm
- Smooth until all air bubbles are removed.
- Trim edges with a very sharp, single edge razor blade. Change your blades often.
- Exposed butt-joints should be installed with factory edge. If not, the products should be cut from the back side to be adjusted the dimensions. (This product can not be double seam cut on the wall.)
- Use a urethane seam roller to set the seams. Avoid over working seams to prevent damage to edges.
- Never allow the adhesive to get on face and/or edges of the material.

4 Cleaning

- Blot excess adhesive, DO NOT rub.
- Dampen the stained area with clean soft cloth soaked with a very mild liquid detergent, if necessary, and dab off it by clear soft dry cloth smoothly.

5 Maintenance

- If necessary, apply a bead from waste material with one drop glue.
- If necessary, apply a fragment made from glass beads being with colored paper which is peeled off from waste material.